



1. Align the GU10/GU5.3 pins of MR16 with the base holes



2. Push the MR16 bulb into the base and rotate clockwise to lock it.