



Instructions

JLS68102-XXTRF

Step 1. Insert one side of the diffuser under the retainers on the troffer. Be careful to engage all the retainer locations.

Step 2. Insert the other side of the diffuser under the retainers. Once again, being sure to engage all of the retainer locations.



Step 3. Remove the protective film from the diffuser.

Step 4. Installation is complete.

